Overview

RXCamView 2.0.1 is compatible with iOS 7.0 and above. It can support live view, remote playback, PTZ control, local playback, snapshot and push notifications etc. from DVR and NVR via 3G or WIFI.

Live View

Click $\overline{\textcircled{O}}$ to go to **Live View** interface.

Open Live View

Under Live View interface, click ^G on top right to go to Devices interface.
Icons on Devices interface:

| Icons | Function |
|--------------|--------------------------------|
| <u></u> | Devices |
| | Channel |
| \odot | Select channel to do live view |
| \leftarrow | Return to live view interface |

 Click device to select channels, and then click Start Live View icon to view the cameras. If it is under multiple channels display mode, you can drag the cameras to reorder the windows.

Icons on Live View:

| Icons | Fuction |
|-----------------|-------------------------|
| 8 | Go to Device List |
| | 4/6/8/9/16 split screen |
| Ð | Add Live View Channel |
| Ô | Snapshot |
| <u>التقا</u> ري | Record |
| <u>يۇر</u> | PTZ Control |
| <u>8</u> | Image Quality Switch |
| □ | Stop Live View |

| ⊴ × | Mute on/off |
|------------|-------------------------|
| 21 | Video Size Switch |
| Ŷ | Voice Intercom Function |

PTZ Control

Click ³⁴ to show PTZ control panel.

| Icons | Function |
|---|---|
| $\land ~ \lor ~ \land ~ \triangleright$ | Tab arrows to move camera side to side or up and down |
| Q | Set speed |
| -Ç ⁻⁾ | Set, call or delete preset point |

Under PTZ control panel, press the arrows to move camera side to side or up and down.

- Click Zoom +/- to Zoom In/Out;
- Click Focus +/- to Focus In/Out;
- Click Iris +/- to Iris In/Out.

Set/Call Preset Points

- 1. Press PTZ control arrows to move the camera to the requested place.
- 2. Click \mathbb{G} to set preset points (1–256).
- Click Set to complete. Slide up and down to select preset points. Click Call to call preset point.

Image Quality Switch

Switch among Main stream, Substream and mobile stream.

Note: Switch image quality will affect image quality of live view and recording on phones.

Zoom

Under Live View, double clik windows to go to full screen, hold or separate fingers to zoom in or zoom out.

Full Screen Display

Under Live View, flip mobile phones to go to full screen display.

Voice intercom

If the device supports voice intercom function, click button can use this function.

Select and delete the live view channel

Select and drag the channel to the upper side of the mobile phone screen, until the background color of the upper side screen turn red and a garbage icon comes out. Then the channel selected will be deleted

Remote Playback

Click to go to **Remote Playback** interface.

Start Playback

• Under **Remote Playback** interface, click \triangle to go to **Devices** interface.

Icons on Devices interface

| Icons | Function |
|--------------|-------------------------------------|
| \odot | Select Channels to do playback |
| <u></u> | Devices |
| | Channels |
| \leftarrow | Return to Remote Playback interface |

• Select date and type from devices list on the top of **Devices** interface and click device name to select channels you would like to replay. Then select **Date** to return to remote playback interface to start playback.

Icons of Remote Playback

| Icons | Function |
|---------------------------------|----------------|
| | Slow Play |
| | Play/Pause |
| $\triangleright \triangleright$ | Fast Forward |
| | Frame by Frame |
| | Stop |
| ſo | Snapshot |

| Ē | Record |
|----|-------------|
| ⊲× | Mute on/off |

• Slide playback time bar can adjust playback time, and hold and drag playback windows can reorder the windows.

Zoom

Double click to enlarge the window, and then hold or separate fingers to Zoom in/out.

Adjust Playback Time

During playback, click \oplus , \oplus under playback time bar to Zoom in/out time.

Full Screen Playback

During playback, flip mobile phones to enlarge to full screen.

Local Playback

Click to go to Local Playback interface.

Start local playback

• Under **local playback** interface, select device from device list to go to **recording files** interface and select the files you would like to replay.

Icons of Local Playback

| Icons | Function |
|-------|----------------|
| | Slow Play |
| | Play/Pause |
| | Fast Forward |
| D | Frame by Frame |
| | Stop |
| ťo | Snapshot |
| <]× | Mute on/off |

Remove recording files

Under **Recording Files** interface, click **edit** to edit, select one or multiple files which you would like to remove. Click **Delete** to remove the files, if you would like to delete all files, click **clear.** Click **Done** to quit.

Remove Devices

Under **Local Playback** interface, hold and move to the left until **Delete button in Red** appears, click Delete to remove.

Zoom

Hold or separate fingers to do Zoom in/out on live view.

Full Screen Playback

During playback, flip mobile phones to enlarge to full screen.

Image Manager

Click to go to Image Manager interface.

Under Image Manager interface, you can view and email snapshots.

Delete Devices

Under **Image Manager** interface, hold and move to left until **Delete button in Red** appears, click **Delete** to remove device.

Send Images

Please follow the following instruction to email images.

Instruction:

- 1. Under **Image Manager** interface, select device to go to **images** interface.
- 2. Select images, and click $\stackrel{\text{$M$}}{\sim}$.

3. Under pop-up email interface, input receiver's email address and email subject. Click **Send** to complete.

Delete Images

Please follow the following instruction to remove multiple images or recording files.

Instructions:

- 1. Click **Edit** to select images you would like to remove.
- 2. Click **Delete** to remove or click **Clear** to clear images.

Image Manager

Instruction:

- Click an image to enlarge it to full screen. You can click [▶] to display images automatically. Click [™] to remove images.
- 2. You can hold or separate fingers to zoom in/out images. Or double click to decrease or enlarge images. Or slide the screen to view next image.

Alarm

Click to go to Alarm interface.

Under Alarm interface, you can set push notifications and view alarm information.

Push Notifications

- 1. Under **Alarm** interface, click ^(b) to go to **Push Set** interface.
- 2. Select device and enable push notifications.

Alarm

- 1. Under **Alarm** interface, you can view alarm received.
- 2. Slide the alarm information to the left until Delete icon appears, and click **Delete** to remove.

3. Click **Clear** to clear all alarm information.

Device Manager

Click to go to **Device Manager** interface.

Add Devices

Add devices by manual

1. Under **Device Manager** interface, click $^+$ to go to **Devices** interface.

2. Input the following information.

- **Device Name:** Device name.
- Type: IP/DOMAIN or Device ID.

IP/DOMAIN: IP address or Domain name.

Device ID: P2P ID.

- Client Port:Client Port.
- User Name: User name of DVR/NVR.
- Password: Password of DVR/NVR.
- Channels: Channels Number achieved from the device automatically.
- 3. Click Save to save.

Scan

If connect by P2P ID, click to scan QR code to add device.

Edit Device

- 1. Under **Device** interface, click Device to view device information.
- 2. Edit device information.
- 3. Click **save** to save.

Remove devices

Under **Device Mangaer** interface, slide the device to left, and then click **Delete** to remove it.