

Dear Customer!

By selecting this VC product you have chosen a professional device, which guarantees highest possible quality and reliability.

Please read the following instructions carefully before commissioning the product in order to be able to take full advantage of all quality features regarding this product line.

Video transmission

Art. no. 18100

Art. no. 18110

Table Of Contents

General Information.....	2
Introduction.....	2
Technical Specifications.....	2
Installation Instructions.....	4
Installation Procedure.....	4
Indicator LEDs.....	5
Troubleshooting.....	6
Limited Warranty.....	7

GENERAL INFORMATION

Introduction:

The 18100 / 18110 Series video transmitter and receiver support simultaneous transmission of one channel of 8-bit digitally encoded video over one multimode or single-mode optical fiber. Plug and Play design ensures the ease of installation and electronic and optical adjustments are never required.

Model Number

Unit Type	Model Number
One-channel Digitally Encoded Video Transmitter	18100
One-channel Digitally Encoded Video Receiver	18110

Technical Specifications:

VIDEO

Video Input:	1 volt pk-pk (75 ohms)
Input/Output Channels:	1
Bandwidth:	5 Hz - 8 MHz
Bit Resolution:	8-bit
Differential Gain:	< 2%
Differential Phase:	< 0.6°
Tilt:	< 1%
S/N Ratio:	>50dB (Weighed)

WAVELENGTH 850/1300nm,Multimode

OPTICAL EMITTER: Laser Diode

NUMBER OF FIBERS 1

CONNECTORS

Optical: ST
Video: BNC
Data: Shield RJ-45 Plug

GENERAL

Power Supply: DC5V @ 300mA
Size: 120mm x 116mm x 30mm
Construction: Aluminum
MTBF: > 100,000 hours
Operating Temp: -20°C to +55°C
Storage Temp: -40°C to +85°C
Relative Humidity: 0% to 95% (no condensing)

INDICATOR

Module
Blue: Video Sync Present
Orange : Power On

OPTICAL POWER BUDGET

Optical transmission distance is limited to optical loss of the fiber and additional loss caused by connectors, splices, and patch panels.

Fiber	Wavelength	Receiver		Transmitter		Optical Power Budget	Max Distance
		Model	Output	Model	Sensitivity		
Multimode	1300nm	18110	-10 dBm	18100	-22 dBm	16 dB	4km

CAUTION!

The transmitter unit contains a laser-emitting diode located in the optical connector. This device emits invisible infrared electromagnetic radiation that can be harmful to human eyes. The radiation from this optical connector, if viewed closely without any protection, may cause instantaneous damage to the retina of the eye. Direct viewing of this LED should be avoided at all times.

INSTALLATION INSTRUCTIONS

Installation Procedure

The 18100 / 18110 video transmission systems series are preset for immediate use. There are indicator LEDs on the units for monitoring the real-time status of video and power. The following instructions describe the typical installation procedure and the function of the LED indicators located on each unit.

1. Connect the video source (camera) to the video input BNC connector on the transmitter unit using coaxial cable.
2. Connect the video output BNC connector on receiver unit to the video monitor using coaxial cable.
3. Connect the fiber optic cable between the transmitter and receiver
4. Apply the power supply to both the transmitter and receiver
5. When the power is applied, the orange POWER LED will light, indicating the presence of operating power. The blue VIDEO LED will give an indication as stated in the following page.
6. The system should now be operational.

Indicator LEDs

The stand-alone units have integral LEDs that are used to monitor the state of the unit. There are one video LED and one power LED on each unit. One, labeled as “PWR”, lights when operating power is present. Another labeled as “VID”, lights when the video input/output signals are detected.

TRANSMITTER and RECEIVER:

Power: ON: (Orange) Indicates that correct power has been applied

Transmitter:

Video: OFF: Indicates no video detected on input BNC connector
(No Video present on input BNC)

ON: (blue) Indicates video detected on input BNC connector
(Video present on input BNC)

Receiver:

Video: OFF: Indicates no video present on output BNC connector
(No Video present on output BNC)

ON: (Blue) Indicates video detected on output BNC connector
(Video present on input BNC)

TROUBLESHOOTING

Optical Fiber

The 18100 / 18110 Series is available with most applications using multimode or singlemode optical fibers. Please be certain that the correct size and type of the fiber is being used for the particular mode transmitter/receiver combination.

Also be certain that the attenuation and bandwidth of the fiber optic cable being used is within the range of the system's loss budget specifications.

General

Any dirt or dust may easily pollute or block the fiber from accepting or radiating light. Therefore, please try to keep the optical connector clear and always use the dust caps whenever the connector is exposed to air. It is suggested that the tip of the optical connected should be carefully cleaned with a lint-free cloth moistened with alcohol from time to time.

The status of any of the VIDEO LED should provide the first clue as to the origin of any operational failure. If the VIDEO LED on the receiver unit is off, it usually means that the fiber is broken or has too much attenuation.

Please also make sure that the transmitter and the receiver are not used in opposite position



VC Videocomponents GmbH
Brachenfelder Str. 45
D-24534 Neumünster
Tel.: ++ 49 (0) 4321 - 39 05 40
Fax: ++ 49 (0) 4321 - 28 04 82
e-mail: mail@vcvideo.de
Internet: www.vcvideo.de

Service
Tel.: ++ 49 (0) 4321 - 3 90 54 33
e-mail: technik@vcvideo.de

All contents of this document may change without prior notice
All rights are reserved.